

<b>Note:</b> All WD-Series Coils are available with the exclusive AC Option. AC is	7. The Removable Power Cord is for
added to the End of the Model Number (I.e., WDV-16-AC)	operators who may want extra mobility
	without the use of an Extension Cord.
Encapsulated in urethane rubber. Ergonomically designed for comfort and use.	8. Pulse DC Option aids in particle
	mobility and ensures the ability to
	perform an Active Field Inspection.
All units supplied with 2.5m (8') 3-16 SOOW power cord.	<b>9.</b> See Web Document Coil Options for
	all available Options.
WD Options	
'K' - Added to any coil designation designates 230VAC 50Hz (Frequency may affect output) CSA, UL, C	
1 - Supplementary Feet also act as handles to aid handling, furthermore they provide a base to keep the coil from rolling.	
2 - Standard Foot Switch recommended for high throughput. Also available on WP-Series Models. Included on WA-Series	
Models or Energize Button at no cost.	
Removable Foot Switch, permits operation with our without the connection of the Foot Switch	
Water Resistant Foot Switch, used in particularly Wet environments with high throughput	
3 - Pulsed DC, permits the operator to perform an Active Field Inspection with a Pulsing Field (80 pulses per minute).	
4 - ID Wear Bars - Upper, to protect the Top Inside Surface of the Coil (Coil dragged on surface of the work piece)	
ID Wear Bars Lower, to protect the Bottom Inside Surface of the Coil (Work piece being dragged on the lower surface)	
Side ID Wear Bars, for large workpieces or Pipeline Preweld Demagnetization	
5 - AC Option, is 4000 Amp Turns on WD-Series Coils 16"ID and under. Not available on WDV-18 and Larger Coils. While	
the AC Option permits AC testing, it also aids Demag procedures as well.	
6 - Automatic Ring-Down for High throughput Demagnetization on common parts.	
7 - Removable Power Cord, for Rough Operators	
8 - Control Housing Liftiing Lugs, for hanging smaller ID Coils, or Lifting larger ID (Heavy) Coils	
9 - Pipe End Centralizer Assemblies, for Pipeline Preweld Demagnetization	
10 - Remote Controls are used when the operator can't reach the standard Controls on top of the Coil, or the Operator needs	
to be removed a short distance from the Coil itself.	



7952 Nieman Road, Lenexa, KS 66214-1560 USA Phone: 913-685-0675, Fax: 913-685-1125 www.ndtsupply.com, sales@ndtsupply.com