

Western Instruments

Established 1965

W-WF Kit (Wet Fluorescent Method)

Spectroline
FL-1700P
12 Volt UV
Lamp Kit



W-WF Kit
Illustrated with a
WC-6 Yoke.

Western's MPI Kits are offered in a great variety of configurations. Our Wet Fluorescent Kit is supplied with 2 of our standard Cases (#3 & #5). Our part number for a WC-6 Wet Fluorescent Kit (as illustrated above) is WC-6-WF. However, any model of Yoke can be supplied and upgraded with a W-WF, with ample room for;

W-WF Kit (Wet Fluorescent Method) includes the following;

(Illustrated with a WC-6)

- #6 Carrying Case
- Aerosol Cans of; (375ml /16 oz.)
 - 4 – Cleaner Remover
 - 4 – Fluorescent Particle Bath
- Economy Pie Gauge
- Field Indicator (Magnetometer).
- Spectroline FL-1700P (12 Volt) Black Light Kit
- #3 Carrying Case
- Western Instruments 7 Amp Hour Battery Pack
- Western Instruments Dual Voltage Charger
- Protective UV Spectacles
- Operator Instructions

Options for BIB-150P or SB-100P Black Lights in #5 Carrying Case.

Note: The W-SWF Kit can be supplied with any model of W-Series Yoke, and is supplied with Sherwin Incorporated® Aerosols, like all of our Wet Method Kits.

The W-DM Kit is Ideal for a shop just starting a Wet Fluorescent Magnetic Particle Inspection Program, or a Field Inspector who wants a Convenient Wet Fluorescent MPI Kit.

W-Series Portable MPI Kits



7952 Nieman Road, Lenexa, KS 66214-1560 USA
Phone: 913-685-0675, Fax: 913-685-1125
www.ndtupply.com, sales@ndtupply.com