

# Western Instruments

Established 1965

## W-WM Kit (Wet Method)

W-WM Kit Illustrated  
with a WC-6 Yoke.



Western's MPI Kits are offered in a great variety of configurations. Our Wet Method Kit is supplied with our standard #6 Case. Our part number for a WC-6 Wet Method Kit (as illustrated above) is WC-6-WM. However, any model of Yoke can be supplied and upgraded with a W-WM Kit, with ample room for the Consumables and a Yoke.

### W-WM Kit (Wet Method) includes the following;

(Illustrated with a WC-6 Yoke)

- #6 Carrying Case
- Field Indicator (Magnetometer).
- Operator Instructions
- Aerosol Cans of; (375ml /16 oz.)
  - 2 – White Contrast Paint
  - 2 – Black Oxide Bath
  - 4 – Cleaner / Remover

Note: The W-WM Kit can be supplied with any model of W-Series Yoke, and is supplied with Sherwin Incorporated® Aerosols, like all of our Wet Method Kits.

The W-WM Kit is Ideal for a shop just starting a Wet Method Magnetic Particle Inspection Program, or a Field Inspector who needs to spend a couple of hours doing a *Black on White* MPI Inspection.

W-Series Portable MPI Kits



7952 Nieman Road, Lenexa, KS 66214-1560 USA  
Phone: 913-685-0675, Fax: 913-685-1125  
[www.ndtsupply.com](http://www.ndtsupply.com), [sales@ndtsupply.com](mailto:sales@ndtsupply.com)