


Boit Pro has three optional operation modes:




1. DIRECT MODE




Item	Power Source	Connection
Laptop	External Power / Laptop battery	-
Panel	External Power	Cable
X-Ray Source	X-Ray Source Battery	Cable or WXR Wireless

2. WIRELESS MODE



Item	Power Source	Connection
Laptop	External Power / Laptop battery	-
ICU	ICU battery	Wireless
Panel	Power from ICU	Cable
X-Ray Source	X-Ray Source Battery	Cable or WXR Wireless

3. ICU MODE



Item	Power Source	Connection
Laptop	External Power / Laptop battery	-
ICU	External Power / ICU battery	Cable
Panel	Power from ICU	Cable
X-Ray Source	X-Ray Source Battery	Cable or WXR Wireless